

HP001F Liste der Einzelteile (V1.0)

Piko Modelle / Nummern / Motornummer:

Modell	Nummern	Motornummer
BR 101	51100 – 51112	51100-36
BR 151, BR 752	51300 – 51317, 51900 – 51905, 51912 – 51914	51300-74
BR 120	51320 – 51339, 51906 – 51908	51320-61
BR 240, CSD S499	51380 – 51395	51380-57
MAV V 43	51430 – 51433	51430-70
E 94, BR 194	51470 – 51476	51470-57
E 41, BR 141, PKP EU06, PKP EU07, PKP EP08, PKP ET41	51510 – 51530 , 96360 - 96383	51510-60, 51510-160
E 91, BR 191	51540 – 51549	51540-63
BR 187, BR 147, FS E.494	51560 – 51596, 96360 - 96383	52510-32, 52510-132
PKP ET21	51600 – 51607	51600-69
ÖBB Rh 1044, Rh 1144	51620 – 51630	51620-66
E 50, E52, BR 150, BR 152, PKP ET22	51640 – 51653, 51820 – 51825, 96330 – 96338	51640-87
BR 103	51670 – 51688	51670-60
BR 112, BR 143, DR BR 212, DR BR 243, BR 755	51700 – 51723, 59117	51700-58
E 10, E 40, BR 110, BR 111, BR 112, BR 140, EP 5, ÖBB Rh 1041, V 200, DR BR 120, MAV M62, PKP ST44, PKP SU 45, CSD T679	51730 – 51759, 51800 – 51814, 51826 – 51859, 51880 – 51897, 51909 – 51911, 52800 – 52819, 52900 – 52909, 96301, 96308 – 96310, 97800	51730-106
ÖBB Rh 1010	51760 – 51774	51760-69
E 18, BR 118, BR 218, ÖBB Rh 1118	51860 – 51878	51860-56
V 160, BR 216	52400 – 52417	52400-70
BR 218	52500, 57200 - 57208	52500 -07, 52500-17, 52500-47
BR 245	52510 – 52524, 59112	52510-32, 52510-132
V 200, BR 221, DR BR 118, BR 132, BR 142, BR 232, Ludmilla, Gysev Rh 648	52570 – 52616, 52760 – 52779, 52910 – 52917, 59116	52600-28
PKP SU46	52860 – 528671	52860-31
ICE	57194, 57305 – 57306, 59006, 59027, 59114 (ICE), 59118 (ICE)	57194-15
Taurus, BR 182, BR 185, BR 189, SBB Re 482, ÖBB Rh 1016, MAV Rh 1047, ES64U2	57210 – 57229, 57280 – 57295, 57410 – 57429, 57480 – 57495, 57810 – 57826, 57910 – 57926, 59026, 95692, 97798	57410-08
BR 146, BR 185, BR 189, Traxx, BR 285, SBB Re 482, SBB Re 484, BLS Re 485	57230 – 57249, 57330 – 57343, 57430 – 57449, 57470 – 57479, 57530 – 57543, 57831 – 57839, 57931 – 57939, 59004 – 59005, 59011, 59013, 59021, 59028 – 59029	57430-08, 57430-108
BR 189, SBB Re 474	57250 – 57279, 57450 – 57469,	57450-08

	57850 – 57865, 57950 – 57966, 97732, 97741 – 97742, 97763, 97779 - 97780	
BR 218	57313 – 57319, 57400, 57510 – 57519, 57800 – 57807, 57900 – 57907, 59007, 59011, 59013	52500-07, 52500-47
ÖBB Rh 2016, Herkules ER 20	57380 – 57398, 57580 – 57598, 57880 – 57894, 57980 – 57994, 59009, 97734-97735	57580-08
BR 218	57401	57401-72
SNCF BB 67400	59010, 97781	95151-37
BR 220, V 180, BR 118, DR BR 119, DR BR 130, DR BR 131, DR BR 229	59020, 59360 – 59364, 59366 – 59388, 59560 – 59564, 59566 – 59589, 59700 – 59722, 59740 – 59757, 59830 – 59840, 59930 – 59941, 97730 – 97731, 97738,	59560-28
BR 146.2, BR 185.2, BR 186, SBB Re 482, Re 486	59040 – 59058, 59064 – 59069, 59140 – 59155, 59340 – 59359, 59365, 59540 – 59559, 59565, 59770 – 59771, 59850 – 59868, 59950 – 59968, , 97744 – 97750, 97754, 97757 – 97758, 97771 – 97772, 97775 – 97776	59540-32, 59540-132
BR 193, BR 247, Vectron, BR E.191, DSB EB 3200, Rh 1216	59080 – 59099, 59113, 59115, 59120 – 59122, 59180 – 59199, 59390 – 59399, 59590 – 59599, 59730 – 59738, 59800 – 59818, 59844 – 59849, 59870 – 59889, 59900 – 59918, 59970 – 59989, 95100, 97736 – 97737, 97739, 97743, 97755 – 97756, 97760 – 97762, 97773 – 97774, 97794 – 97796	59900-32
PKP SU 45	96302 – 96307	96300-26
SNCF BB 17000, BB 25000, BB 25500, BB 8634	96500 – 96524	96502-29
SNCB Reeks 20, Reeks 120, Reeks 2800	96540 – 96567	96540-38
SNCF CC 25000	96580 – 96595	96580-68